

## Hanging instructions

Store material in a clean, dry place. Do not crush, crease, fold or bend.

Prior to cutting, inspect each roll for damages, defects, and verify that you have received the correct design and color. If you have any questions or problems after hanging the first 3 strips, contact us at *info@tissagemahieu.com*. We will not accept claims after more than 3 strips have been cut and installed.

These instructions are provided as a general guide. Installation by a professional wallcovering installer is recommended for best results.

- 1. Install wallcovering at room temperature
- 2. *Wall surface* should be clean, dry, smooth, of uniform color, and properly primed and sealed. For best results, the primer color should be similar to the wallcovering color
- 3. Apply a heavy-duty, ready mixed PVA or EVA *clear wallcovering adhesive* to the wall. Follow the instructions of the adhesive manufacturer. Make sure the adhesive is spread out evenly
- 4. Table-cutting or double-cutting on the wall is at the discretion of the installer. Use a *new blade for each trim*
- 5. Allow adhesive to set-up on the wall before hanging, so that it's sufficiently tacky not to bleed through to the surface of the fabric
- 6. Install fabric strips straight up, as they come off the bolt, and in consecutive order
- 7. Seams should be no closer than 6 inches to corners
- 8. Avoid excessive pressure to the surface of the fabric during installation which may cause adhesive to bleed through to the surface
- 9. Excess *adhesive on the material* can be allowed to dry and then removed with a dry brush, or can be removed immediately with a wet sponge

## Maintenance tips

To avoid stains being absorbed immediately, it is required to wipe off with a clean sponge or tissue. If needed, use lukewarm water.

Hard rubbing should be avoided in order not to damage the fabric. Careful vacuum cleaning is allowed.

Tissage Mahieu NV Posterijstraat 54 8793 Waregem Belgium T. +32 56 60 20 37 *info*@tissagemahieu.com

